Release note for FW 3.9

New features in FW 3.9 is:
- Separate initial brake and drag brake setting
- Separate Fwd & Brk Switch frequency setting.

1. Drag Brake

It's now possible to set the drag brake in percent of full brake.
Settings range: 0 – 100%
0 means drag brake is disabled.
Drag brake can now be fine tuned without affecting the brake setting (initial brake setting).

All five brake profiles are still individual and have their own feeling.

2. Switch Frequency

Brake switch frequency can be adjusted between 1k – 16kHz.
Forward switch frequency is still adjustable in similar way.
The Switch frequency affects all profiles.
The set Brake switch frequency is used on all 5 brake profiles.
The set Forward switch frequency is used on all 5 Forward profiles.