F1 Rear Wing Set User manual

Insert (2) M3x14 screws into the rear wing mount. Insert (2) 2mm spacers on each screw.



2 Slide the rear wing mounting screws through the rear wing mount and secure with (2) M3 lock nuts



Rear wing installation completed.

