X – 5 Set-Up Sheet			
Driver: Ellis Stafford			Date: 11-5-08
Track: Oswestry Grass			
Tight/Open 1=very tight 5=very open 3	Wet/Dry 1=very wet 5=very dry	Smooth/Rough 1=very smooth 5=very rough 2	Slippery/High-Bite 1=very slick 5=very high bite 4
Front			
Suspension			Shocks
Ride Height: <u>Driveshafts level</u>			Losi 🔀 / Associated 🗌
Camber: $\underline{-1}^{\circ}$ Toe: $\underline{\ln 0}^{\circ}$ Out $\underline{1}^{\circ}$			Oil Make: <u>Losi</u>
Camber Link: Inside: $\frac{1}{1 = inside}$			Mounting (Top/Bottom): $\underline{2} / \underline{1}$
Castor Block Height: Std/Cut:Cut Flush Washers: 0x Gold			Spring: <u>Green</u>
Roll Bar: No Size:			Piston: Orange Std /Drilled Standard
Diff/One Way/Spool: One Way Driveshafts: CVD's Steel			Oil: <u>40wt</u>
Outdrives Plastic/Metal: Plastic			Limiting (In/Out): 2mm/
CVD's/LCD's: <u>CVD's</u>			Internal Spring: No
Washers Under Bellcranks: <u>0</u> Under Knuckle Arms: <u>2</u>			
Steering Ackerman In/Out : <u>In</u>			
Rear			
Suspension			Shocks
Rear Hanger flipped: <u>Flipped</u> Antisquat: <u>2</u> °			Losi ⊠/Associated □ Oil Make: <u>Losi</u>
Ride Height: <u>Driveshafts just below level</u>			Oli Make. <u>Losi</u>
Camber: <u>-1</u> ° Toe In: <u>Inside</u> °			Mounting (Top/Bottom):4/1
Camber Link: Inside: 7 1=inside/8=outside Bottom Outside: C A=inside			Spring: White
Hub Spacing (Long/Medium/Short): Medium			Piston: <u>Blue</u> Std/Drilled <u>Standard</u>
Diff Position: A Back			Oil: <u>25wt</u>
Diff (Plastic/Metal): Metal Roll Bar: No Size:			Limiting (In/Out): 2mm/
Driveshafts (Dogbone/CVD's Ally/Steel): <u>Dogbones Steel</u>			
Other			
Notes: New steering being tested			
Front Tire: Schumacher Yellow minispikes inner and outer 2 rows cut off			
Rear Tire: Schumacher Yellow minispikes			
Motor: 5.5 sintered (12.5mm) Pinion/Spur: <u>17/108</u>			
Wing: Standard X5 half gurney			