X - 5 Set-Up Sheet	
Driver: Ellis Stafford	Date: 18-2-07
Track: Batley Super Cup Indoor	
Tight/Open   Wet/Dry   Smooth/Rough   1=very tight 5=very open   4   5   5   2   4	Slippery/High-Bite 1=very slick 5=very high bite Carpet/ polished floor 4
Front	
Suspension	Shocks
Ride Height: <u>Driveshafts just below level</u> Camber: -1° Toe: In <u>0</u> ° Out <u>1</u> °	Losi ⊠/ Associated ☐ Oil Make: <u>Losi</u>
	Mounting (T. (D. () ) 2 /1
Camber Link: Inside: 1   Teinside	Mounting (Top/Bottom): $\underline{2} / \underline{1}$
Castor Block Height: Std/Cut:Cut Flush Washers: 2x Gold	Spring: <u>Silver</u>
Roll Bar: No Size:	Piston: Red Std /Drilled Standard
Diff/One Way/Spool: One Way Driveshafts: LCD's	Oil: <u>35wt</u>
Outdrives Plastic/Metal: Plastic	Limiting (In/Out): 2mm/
CVD's/LCD's: <u>LCD's</u>	Internal Spring: No
Washers Under Bellcranks: <u>0</u> Under Knuckle Arms: <u>0</u>	
Steering Ackerman In/Out: <u>In</u>	
Rear	
Suspension	Shocks
Rear Hanger flipped: Flipped Antisquat: 2°	Losi ⊠/Associated □
Ride Height: <u>Drivshafts just below level</u>	Oil Make: <u>Losi</u>
Camber: <u>-1</u> ° Toe In: <u>Inside</u> °	Mounting (Top/Bottom):2/1
Camber Link: Inside: 8 Outside: C	Spring: <u>Red</u>
Hub Spacing (Long/Medium/Short): Short	Piston: <u>Blue</u> Std/Drilled <u>Standard</u>
Diff (Plastic/Metal): Metal Roll Bar: No Size:	Oil: <u>30wt</u>
	Limiting (In/Out): A spacer/B spacer
Driveshafts (Dogbone/CVD's Ally/Steel): <u>Dogbones Steel</u>	
Other	
Notes:	
Front Tire: Schumacher Yellow Minis	
Rear Tire: Schumacher Yellow Minis  Motor: Negrow 5.5  Dinion/Spur: 12/100	
Motor: Nosram 5.5 Pinion/Spur: 13/100 Wing: Standard X5 half gurney	