X – 6 Set-Up Sheet	
Driver: Ellis Stafford	Date: 9-6-07
Track: Bury Metro	
Tight/Open   Wet/Dry   Smooth/Rough   1=very tight 5=very open   2   2   2   3	Slippery/High-Bite 1=very slick 5=very high bite 5
Front	
Suspension	Shocks
Ride Height: Arms level	Losi  Associated  Oil Make: Losi
Camber: $\underline{-1}^{\circ}$ Toe In/Out: $\underline{Out}$ $\underline{1}^{\circ}$	511 Marc. <u>1551</u>
Camber Link: Inside: $\underline{\underline{2}}$ Washers: $\underline{\underline{1}}$ Outside: $\underline{\underline{B}}$ A=inside	Mounting (Top/Bottom): 2/2
Caster Block (20°/25°/30°): <u>25</u> °	Spring: Black
Castor Block Position (Forward/Back): Forward	Piston: Black Std/Drilled Standard
Bump Steer Spacers 0.05" (Stock 2)/Other: 2	Oil: <u>35wt</u>
Spacers under inner Tie-Rod Ballstud: <u>3</u> Axle Trailing (Trailing/Inline): <u>Trailing (stock)</u>	Limiting (In/Out): <u>0mm/</u>
Axle Height Top/Middle/Bottom: <u>Top</u>	
Steering Ackerman Forward (stock)/Back: Forward (stock)	
Rear	
Suspension	Shocks
Transmission Height (Multiples of 0.3"): <u>0.6</u>	Losi ⊠/Associated □ Oil Make: Losi
Ride Height: Arms just above level	
Camber: $\underline{-1}^{\circ}$ Toe Bar $3^{\circ}/4^{\circ}$ : $\underline{3^{\circ}}$ Antisquat: $\underline{1^{\circ}}$	Mounting (Top/Bottom): $\underline{1/2}$
Extra Hub Toe In/Out: No/	Spring: Pink
Camber Link: Inside: $\frac{3 \text{ low}}{1=\text{inside}}$ Outside: $\frac{C}{A=\text{inside}}$	Piston: Red Std/Drilled Drilled
T=inside A=inside  Washers Under Inner Ballstud: 0	Oil: <u>35wt</u>
Hub Spacing Forward/Middle/Back: Forward	Limiting (In/Out): <u>0mm/</u>
Arm Spacing Forward/Middle/Back: Back	
Other	
Notes: Ray speed rear hubs fitted with 1 washers under the ball plus 2mm lower. BK2 rear axle to give more droop. My short link on the rear. 30 grams of weight in the rear motor bay.	
Front Tire: Schumacher Yellow Minispike	
Rear Tire: Schumacher Yellow Minispikes	
Motor: 6.5 Pinion/Spur: 20/81 Wing: X6 no gurney but moved forward.	
mag. 120 no game, out mo rea 101 mara.	