

XRAY XB4 2WD

COMMENTS
130g under saddle packs. Rear shock ends unthreaded four turns.

FRONT

STEERING BLOCK

PLASTIC

☐

LONGER BUSHINGS

UP

☐

DOWN

☒

CASTER BLOCK

PLASTIC

☐

DOWNSTOP

mm

SHIM

0 mm

UPPER SHOCK POSITION

FRONT ROLL CENTER

3 2 1

3 2 1

REAR ROLL CENTER

1 2 3

3 2 1

FRONT LOWER SHOCK POSITION

2 1

2 1

REAR LOWER SHOCK POSITION

1 2

1 2

HUB POSITION

1 2

1 2

UPRIGHT

PLASTIC

☒

DOWNSTOP

mm

FRONT

REAR

OFFSET

STANDARD

☒

+0.75mm

☐

-0.75mm

☐

CASTER

6°

☒

9°

☐

BUMP STEER SHIM

2 mm

WHEELBASE SHIM POSITION

0mm

☒

0 2mm

☐

SHOCK TOWER POSITION

FRONT

☐

REAR

☒

SHOCK POSITION

FRONT

☐

REAR

☒

WING TYPE

STANDARD

☒

WING CUTTING LINE

+

☐

0

☐

-

☒

OFFSET

STANDARD

☒

+0.75mm

☐

-0.75mm

☐

FRONT

REAR

FF

FR

1°

☐

0.5°

☐

ROLL CENTER

1°

☐

0.5°

☐

ECCENTRIC BUSHINGS

1°

☒

0.5°

☐

RF

RR

FRONT

REAR

FRONT TOE

1

OUT

☐

ARM SHIM

0 mm

ACKERMANN POSITION

2 1

BUMP STEER SHIM

6 mm

SHIM UNDER STEERING PLATE

☐

SERVO SAVER

TIGHT

☒

MEDIUM

☐

SOFT

☐

REAR TOE

5

IN

☐

ARM SHIM

0 mm

FRONT

REAR

FRONT CAMBER

-1

SHOCK PRELOAD

mm

FRONT ARM

STANDARD

☒

GRAPHITE ARM STIFFENERS

YES

☐

NO

☒

RIDE HEIGHT

21 mm

SHOCK PRELOAD

mm

REAR CAMBER

-1

REAR ARM

STANDARD

☒

GRAPHITE ARM STIFFENERS

YES

☐

NO

☒

RIDE HEIGHT

20 mm

FRONT

REAR

CHASSIS FLEX

SCREW USED

☐

SCREW NOT USED

☒

CHASSIS

STANDARD

☐

CHASSIS FLEX

SCREW USED

☐

SCREW NOT USED

☒

CHASSIS FLEX

SCREW USED

☐

SCREW NOT USED

☒

CHASSIS FLEX

SCREW USED

☐

SCREW NOT USED

☒

FRONT

REAR