

Front suspension mount bushing pairings

Suspension arm pin position	Width				Kick-up
	Standard		+1mm		
	Front	Rear	Front	Rear	
Hi					12°
					10°
					8°
Low					12°
					10°
					8°

Arn0

Rear suspension mount bushing pairings

Front	Rear					Toe angle
Anti-squat	0°	1°	2°	3°	4°	
						-0.5°
						3°
						+0.5°
						-0.5°
						3°
						+0.5°

Arn0