



FWD Mounting Guide for Blitz Mk10



Team Titan BLITZ MK10 FWD 190mm (0.7 mm) Hatchback Clear Bodyfront wheel drive bodyshell
part number = TT-60239-07



We recommend for the IRIS FWD that this bodyshell is mounted slightly forward on the car: 2-3mm (see following page for body hole measurements).

Wheel arches are then cut slightly further back than the moulded cut lines.

We also recommend that the bodushell is cut 2mm above the side and front mould lines. Wheel arches are then cut slightly higher than the moulded cut lines.



Front body hole measurements



Rear body hole measurements



Cut initially to upper mould line and trim down from there to tune.

Use included wing mounts with holes cut to moulded dots in rear wing and wing support on the body.

Cut front of wing to the mould line.



Added 1.0mm diameter carbon rod with UV glue to prevent rear body tucks.



Added foam to space out body to front bumper.

Mark Burgess, IRIS UK Team Manager

Version 1.0 published Junel 2026

