X – 6 Set-Up Sheet	
Driver: Paul Sinclair	Date: Dec 11, 2007
Track: General Starting Set-up, 4 Gear Transmission, Associated Shocks	
□ Tight / □ Open □ Wet / □ Dry □ Smooth / □ Rough Slippery □ □ □ □ □ High-Bite	
Front	
Suspension	Shocks
Ride Height: _Arms Level	■ Associated / □ Losi
Camber: $\underline{-1}^{\circ}$ Toe: $\underline{1}^{\circ}$ In $/ \square$ Out	Mounting (T/B): 1 / 2
Camber Link: Inside: $\underline{\underline{1}}_{\overline{1=\text{inside}}}$ Washers: $\underline{\underline{2}}$ Outside: $\underline{\underline{B}}_{\overline{A=\text{inside}}}$	Spring: Black
Caster Block: $\Box 20^{\circ} \ \Box 25^{\circ} (stock) = 30^{\circ}$	Piston: $\underline{\#2}$ $\blacksquare$ Std / $\square$ Drilled
□ Back ■ Forward (stock)	Oil: <u>35</u>
Bump Steer Spacers: ■ .050" (Stock) / □ Other: (Spacers under outer Tie-Rod Ballstud)	Limiting (T/B): <u>0/2 turn ext.</u>
Axle: ■ Trailing (stock) / □ Inline	
Axle Height: ■ Top □ Middle □ Bottom	
Steering Ackerman: ■ Forward (stock) □ Back	
Rear	
Ttoui	
Suspension	Shocks
	Shocks ■ Associated / □ Losi
Suspension	■ Associated / □ Losi
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u> Ride Height: <u>CVDs level</u>	
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u>	■ Associated / □ Losi
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u> Ride Height: <u>CVDs level</u>	■ Associated / □ Losi  Mounting (T/B): 2* / 1  I=inside, * denotes CF tower
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u> Ride Height: <u>CVDs level</u> Camber: <u>-1</u> ° Toe Bar: □ 3° ■ 4° Antisquat: <u>.090" (2°)</u>	■ Associated / □ Losi  Mounting (T/B): 2* / 1  I=inside, * denotes CF tower  Spring: Green
Suspension  Transmission Height: $\Box$ .060 (stock) $\blacksquare$ Other: $\underline{0}$ Ride Height: $\underline{CVDs \ level}$ Camber: $\underline{-1}^{\circ}$ Toe Bar: $\Box$ 3° $\blacksquare$ 4° Antisquat: $\underline{.090}$ " (2°)  Camber Link: Inside: $\underline{2}$ Washers: $\underline{0}$ Outside: $\underline{B}$	■ Associated / □ Losi  Mounting (T/B): 2* / 1  l=inside, * denotes CF tower  Spring: Green  Piston: #2 ■ Std / □ Drilled
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u> Ride Height: <u>CVDs level</u> Camber: <u>-1</u> ° Toe Bar: □ 3° ■ 4° Antisquat: <u>.090" (2°)</u> Camber Link: Inside: <u>2</u> Washers: <u>0</u> Outside: <u>B</u> Hub Spacing: □ Forward □ Middle ■ Back	■ Associated / □ Losi  Mounting (T/B): 2* / 1  l=inside, * denotes CF tower  Spring: Green  Piston: #2 ■ Std / □ Drilled  Oil: 30
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u> Ride Height: <u>CVDs level</u> Camber: <u>-1</u> ° Toe Bar: □ 3° ■ 4° Antisquat: <u>.090" (2°)</u> Camber Link: Inside: <u>2</u> Washers: <u>0</u> Outside: <u>B</u> Hub Spacing: □ Forward □ Middle ■ Back  Arm Spacing: ■ Forward □ Middle □ Back  Other	■ Associated / □ Losi  Mounting (T/B): 2* / 1  l=inside, * denotes CF tower  Spring: Green  Piston: #2 ■ Std / □ Drilled  Oil: 30  Limiting (T/B): 0/1 turn ext.
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u> Ride Height: <u>CVDs level</u> Camber: <u>-1</u> ° Toe Bar: □ 3° ■ 4° Antisquat: <u>.090" (2°)</u> Camber Link: Inside: <u>2</u> Washers: <u>0</u> Outside: <u>B</u> Hub Spacing: □ Forward □ Middle ■ Back  Arm Spacing: ■ Forward □ Middle □ Back	■ Associated / □ Losi  Mounting (T/B): 2* / 1  1=inside, * denotes CF tower  Spring: Green  Piston: #2 ■ Std / □ Drilled  Oil: 30  Limiting (T/B): 0/1 turn ext.
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u> Ride Height: <u>CVDs level</u> Camber: <u>-1</u> ° Toe Bar: □ 3° ■ 4° Antisquat: .090" (2°)  Camber Link: Inside: 2 Washers: <u>0</u> Outside: B  Hub Spacing: □ Forward □ Middle ■ Back  Arm Spacing: ■ Forward □ Middle □ Back  Other  Notes: Losi BK II CVD axles. JConcepts front wing. T of droop in it, especially in the rear. The rear also feels steering, shim front axle down, or try the E-Speed camb	■ Associated / □ Losi  Mounting (T/B): 2* / 1  l=inside, * denotes CF tower  Spring: Green  Piston: #2 ■ Std / □ Drilled  Oil: 30  Limiting (T/B): 0/1 turn ext.  his set-up should have a lot really soft. For more
Suspension  Transmission Height: □ .060 (stock) ■ Other: □ 0  Ride Height: □ CVDs level  Camber: □ 1 ° Toe Bar: □ 3° ■ 4° Antisquat: 090" (2°)  Camber Link: Inside: 2 Washers: □ Outside: B  Hub Spacing: □ Forward □ Middle ■ Back  Arm Spacing: ■ Forward □ Middle □ Back  Other  Notes: Losi BK II CVD axles. JConcepts front wing. Tof droop in it, especially in the rear. The rear also feels steering, shim front axle down, or try the E-Speed cambe SMC IB 4200 cells. GTB speed controller.	■ Associated / □ Losi  Mounting (T/B): 2* / 1  l=inside, * denotes CF tower  Spring: Green  Piston: #2 ■ Std / □ Drilled  Oil: 30  Limiting (T/B): 0/1 turn ext.  his set-up should have a lot really soft. For more
Suspension  Transmission Height: □ .060 (stock) ■ Other: 0  Ride Height:CVDs level  Camber:1 ° Toe Bar: □ 3° ■ 4° Antisquat: .090" (2°)  Camber Link: Inside: 2 Washers: 0 Outside: B  Hub Spacing: □ Forward □ Middle ■ Back  Arm Spacing: ■ Forward □ Middle □ Back  Other  Notes: Losi BK II CVD axles. JConcepts front wing. T of droop in it, especially in the rear. The rear also feels steering, shim front axle down, or try the E-Speed camb SMC IB 4200 cells. GTB speed controller.  Front Tire:	■ Associated / □ Losi  Mounting (T/B): 2* / 1  l=inside, * denotes CF tower  Spring: Green  Piston: #2 ■ Std / □ Drilled  Oil: 30  Limiting (T/B): 0/1 turn ext.  his set-up should have a lot really soft. For more
Suspension  Transmission Height: □ .060 (stock) ■ Other: <u>0</u> Ride Height: <u>CVDs level</u> Camber: <u>-1</u> ° Toe Bar: □ 3° ■ 4° Antisquat: .090" (2°)  Camber Link: Inside: 2 Washers: <u>0</u> Outside: B  A=inside  Hub Spacing: □ Forward □ Middle ■ Back  Arm Spacing: ■ Forward □ Middle □ Back  Other  Notes: Losi BK II CVD axles. JConcepts front wing. T of droop in it, especially in the rear. The rear also feels steering, shim front axle down, or try the E-Speed camb SMC IB 4200 cells. GTB speed controller.  Front Tire:  Rear Tire:	■ Associated / □ Losi  Mounting (T/B): 2* / 1  l=inside, * denotes CF tower  Spring: Green  Piston: #2 ■ Std / □ Drilled  Oil: 30  Limiting (T/B): 0/1 turn ext.  his set-up should have a lot really soft. For more per link hangers in the rear.
Suspension  Transmission Height: □ .060 (stock) ■ Other: 0  Ride Height:CVDs level  Camber:1 ° Toe Bar: □ 3° ■ 4° Antisquat: .090" (2°)  Camber Link: Inside: 2 Washers: 0 Outside: B  Hub Spacing: □ Forward □ Middle ■ Back  Arm Spacing: ■ Forward □ Middle □ Back  Other  Notes: Losi BK II CVD axles. JConcepts front wing. T of droop in it, especially in the rear. The rear also feels steering, shim front axle down, or try the E-Speed camb SMC IB 4200 cells. GTB speed controller.  Front Tire:	■ Associated / □ Losi  Mounting (T/B): 2* / 1