



Reedy Blackbox Link 2.1 Instructions

By downloading and installing the Blackbox Link 2.1 PC program, you can install the latest performance updates for your Blackbox PROgrammer2 and Blackbox 510R and 850R ESCs.

1. Download the Blackbox Link 2.1 program and install it on your PC:
2. Close all other programs, then open the ESC update program.
3. Plug a USB-to-mini-USB cable into an available USB port on your PC and into your PROgrammer2's USB port. The connection will be verified by a "USB Connection" green light:

[DOWNLOAD](#)



4. If you plan to update your PROgrammer2, select "Program Box." The connection will be verified by a "Program Box Connection" green light:



5. If you plan to update your ESC, plug the PROgrammer2's extension wire into the programming port on your ESC and select "ESC." Power on the ESC. The connection will be verified by a "ESC Connection" green light.



6. Click "Select" to choose the file that you wish to install. Double-click the file or click "open" and the file will automatically install.
7. The newly installed firmware file number will appear in the "Firmware Version" window and is the signal that the process is complete.
8. Disconnect PROgrammer2 extension wire from the ESC and the mini-USB connector from the PROgrammer2.
9. Your device is now updated and ready to use.

