

En Instruction Manual
De Bauanleitung
Fr Manuel de montage

www.HBRACING.com

E817

COMPETITION 1/8 SCALE 4WD ELECTRIC BUGGY



Thank you

Thank you for selecting this HB Racing product! This kit is designed to be fun to drive and uses top quality parts for durability and performance. The instruction manual you are reading was designed to be easy to follow yet thorough in its explanations. HB Racing wants you to enjoy driving your new HB Racing product. If you come across any problems or need some help getting through a step, give us a call and we will do our very best to help you. You can also contact us on the internet at www.hbracing.com

- This is a high performance R/C kit, and it requires regular maintenance for best performance. If you don't do regular maintenance the performance will suffer. HB Racing has all the necessary parts and accessories available to keep your car performing at its best.

The caution or attention symbols will warn you about steps that can be very dangerous.
Please read and understand the instructions carefully before proceeding.



Caution

Failure to follow these instructions can damage your kit, and cause serious bodily injury or death.



Attention

Failure to follow these instructions can cause injury to yourself or others. You might also cause property damage or damage to your kit.



Caution

Before Running

- Please read manual with parent or guardian (responsible adult).

Before Operating

- Make sure that all screws and nuts are properly tightened.
- Always use fresh batteries for transmitter and receiver to avoid losing control of the model.
- Make sure no one else is using the same radio frequency as you are using.
- Please confirm the range of the radio operation.

During Running

- Please do not run on a public street, this could cause serious accidents, personal injuries and/or property damage.
- Please do not run near pedestrians or small children.
- Please do not run in small or confined areas.

After Running

- Turn OFF receiver first, then turn OFF transmitter. This will prevent the car from losing control.

Battery Safety

- Please be careful when handling the battery. It will be hot after running. If the wire is frayed, a short circuit can cause a fire.



4 TIME WORLD CHAMPIONS

www.HBRACING.com

Danke

Vielen Dank, dass Sie sich für HB Racing entschieden haben! Dieses Auto soll Spaß machen und verwendet nur hochwertige Materialien für beste Leistungen und Haltbarkeit. Die Anleitung, die Sie gerade lesen, ist einfach zu verstehen und dabei sehr ausführlich. HB Racing will, dass Sie Erfolg und Spaß mit Ihrem neuen Modell haben! Falls es dennoch einmal zu Problemen kommen sollte, melden Sie sich bei uns. Wir werden alles in unserer Macht stehende tun, um zu helfen. Sie können uns auch gerne unter www.hbracing.com kontaktieren.

- Dies ist ein hochleistungs RC-Auto und benötigt regelmäßige Wartung. Wenn Sie diese Wartungsarbeiten nicht durchführen wird die Leistung des Autos darunter leiden. Alle zur Wartung benötigten Teile sind bei HB Racing erhältlich.

Die Warnsymbole weisen Sie auf gefährliche Bauabschnitte hin.
Bitte lesen und verstehen Sie die Anweisungen bevor Sie sie durchführen.



Warnhinweise

Wenn Sie diesen Anweisungen nicht folgen, können Sie oder Ihr Auto Schäden davontragen.



Achtung

Wenn Sie diesen Anweisungen nicht folgen, können Sie oder andere verletzt werden. Es kann auch sein, dass dabei Sachschaden an anderen Dingen oder Ihrem Auto entsteht.



Warnhinweise

Vor dem Fahren

- Bitte lesen Sie die Anleitung (zusammen mit einem Erwachsenen/Erziehungsberechtigten).

Vor dem Betrieb

- Stellen Sie sicher, dass alle Schrauben und Muttern korrekt sitzen.
- Verwenden Sie immer volle Batterien für den Sender und Empfänger, um Empfangsstörungen zu vermeiden.
- Stellen Sie sicher, dass niemand anderes die gleiche Frequenz verwendet.
- Überprüfen Sie die Reichweite der RC-Anlage.

Während dem Fahren

- Fahren Sie nicht auf öffentlichen Straßen. Dies kann zu schweren Unfällen mit Personen- oder Sachschäden führen.
- Fahren Sie nicht in der Nähe von Fußgängern oder kleinen Kindern.
- Fahren Sie nicht auf zu kleinen oder zu eng begrenzten Geländen.

Nach dem Fahren

- Schalten Sie den Empfänger aus, dann erst den Sender. Dies verhindert, dass das Auto außer Kontrolle gerät.

Hinweise zum Fahrakku

- Geben Sie im Umgang mit dem Fahrakku bitte Acht. Er ist nach dem Fahren sehr heiß. Falls die Kabel beschädigt sind, kann ein Kurzschluss ein Feuer auslösen.

Merci

Merci d'avoir choisi ce produit HB Racing! Ce kit a été conçu pour être amusant à conduire, et utilise des pièces de la plus haute qualité pour la longévité et les performances. Le manuel d'utilisation qui est entre vos mains a été conçu pour vous fournir des explications faciles à suivre mais complètes. HB Racing espère que vous aurez plaisir à piloter votre nouveau kit radio-commandé. Si vous rencontrez des problèmes ou si vous avez besoin d'aide pour une étape, appelez-nous et nous ferons de notre mieux pour vous aider. Vous pouvez aussi nous contacter par Internet sur www.hbracing.com.

- Ceci est un kit radio-commandé de hautes performances, et requiert un entretien régulier pour donner le meilleur de lui-même. Si vous n'effectuez pas un entretien régulier, les performances en souffriront. HB Racing a toutes les pièces et les accessoires nécessaires pour maintenir les performances de votre véhicule à leur meilleur niveau.

Les symboles attirant votre attention vous avertiront des étapes qui peuvent être très dangereuses. Veuillez lire soigneusement les instructions et bien les comprendre avant toute utilisation.



Précautions

En ne suivant pas ces instructions vous pourriez endommager votre kit, et provoquer de sérieux dégâts corporels ou même mortels.



Attention

En ne suivant pas ces instructions vous pourriez vous blesser vous-même ou blesser d'autres personnes. Vous pourriez également provoquer des dégâts matériels ou endommager votre kit.



Précautions

Avant de mettre en marche

- Veuillez lire le manuel avec un parent ou un adulte responsable.

Avant de mettre en marche

- Vérifiez que toutes les vis et les boulons sont correctement serrés.
- Utilisez toujours des batteries nouvellement chargées pour l'émetteur et le récepteur afin d'éviter de perdre le contrôle du véhicule.
- Vérifiez que personne d'autre n'utilise la même fréquence radio que vous.
- Vérifiez le champ d'action du fonctionnement de la radio.

Pendant le fonctionnement

- Ne faites pas fonctionner sur une voie publique, cela pourrait provoquer des accidents graves, des blessures corporelles et/ou des dommages aux biens.
- Ne faites pas fonctionner à proximité de piétons ou d'enfants en bas âge.
- Ne faites pas fonctionner dans des lieux petits ou fermés.


Après l'arrêt

- Éteignez d'abord le récepteur, puis l'émetteur. Cela empêchera une éventuelle perte de contrôle du véhicule.

Sécurité de la batterie

- Faites très attention lorsque vous manipulez la batterie. Elle sera très chaude après utilisation. Si un câble était dénudé, un court-circuit pourrait provoquer un incendie.

Equipment Needed
Benötigtes Zubehör
Équipement nécessaire




If you do not use a charger designed to charge Nickel Metal Hydride / LiPo batteries, the batteries will be damaged.
 Wenn Sie keinen geeigneten Lader zum Laden der Nickel-Metall-Hydrid oder LiPo Akkus verwenden, werden die Akkus beschädigt.
 Si vous n'utilisez pas un chargeur conçu pour recharger les batteries Nickel Métal Hydride ou LiPo, celles-ci seront endommagées.


Tools Werkzeuge Outils

Tools needed for assembly. Sold separately.


Zum Zusammenbau benötigtes Werkzeug. Separat erhältlich.
Outils nécessaires pour la mise en place, vendus séparément.



Side Cutters
Seitenschneider
Pinces coupantes




Needle Nosed Pliers
Flachzange
Pince à bec fin




Allen Wrench 1.5mm / 2.0mm / 2.5mm / 3.0mm
Inbusschlüssel 1.5mm / 2.0mm / 2.5mm / 3.0mm
Clé Allen 1.5mm / 2.0mm / 2.5mm / 3.0mm




Hobby Knife
Modellbaumesser
Couteau de modélisme



Cross Wrench
Kreuzschlüssel
Clé en croix




Screwdrivers
Schraubenzieher
Tournevis



Tumbuckle Wrench
Spurstangenschlüssel
Clé à bielles



Reamer
Karosserieloch-Bohrer
Alésoir



Calipers
Messschieber
Pied à coulisse



Thread Lock (Red)
Schraubensicherung (Rot)
Frein A Filet (Rouge)



Grease
Fett
Graisse

Instant Cement
Sekundenkleber
Colle rapide



Air Filter Oil
Luftfilter Öl
Huile p. Filtre a air



Paint
Lexanfarbe
Peinture



Included Items Enthaltenes Werkzeug Éléments inclus



ORI44408
Silicone Oil #500
Silikon Daempferoel #500
Huile silicone 500



ORI44415
Silicone Oil #2,000
Silikon Daempferoel #2,000
Huile silicone 2,000



ORI44416
Silicone Oil #3,000
Silikon Daempferoel #3,000
Huile silicone 3,000



ORI44418
Silicone Oil #5,000
Silikon Daempferoel #5,000
Huile silicone 5,000

Caution Achtung Attention



Do not run in water or sand.
Fahren Sie nie in Wasser oder Sand.
Ne faites pas fonctionner dans l'eau ou sur le sable.

Do not run on public streets or highways. This could cause serious accidents, personal injuries, and/or property damage.
Fahren Sie niemals auf öffentlichen Straßen. Dies kann zu schweren Unfällen mit Personen- und Sachschäden führen.
Ne faites pas fonctionner sur la voie publique ou la route. Cela pourrait provoquer des accidents graves, des blessures corporelles ou des dommages aux biens.



STEP A-01

Front
Vorne
Avant

2x Make 2
2 Stück 2 fois



Rear
Hinten
Arrière

2x Make 2
2 Stück 2 fois



Move the shaft up and down slowly to remove all air bubbles.
Bewegen Sie die Kolbenstange langsam nach oben und unten, damit Luftblasen entweichen können.
Déplacez l'axe vers le haut et vers le bas doucement pour faire partir toutes les bulles.

ORI44408
Silicone Oil #500
Silikon Daempferöl #500
Huile silicone 500





STEP B-01

Front
Vorne
Avant

1x Make 1
1 Stück 1 fois


Rear
Hinten
Arrière

1x Make 1
1 Stück 1 fois



Z086
Flat Head Screw M3x18mm

2
mm



#5,000



! Front
Vorne
Avant

ORI44418
Silicone Oil #5,000
Silikon Daempferoel #5,000
Huile silicone 5,000

#2,000



! Rear
Hinten
Arrière

ORI44415
Silicone Oil #2,000
Silikon Daempferoel #2,000
Huile silicone 2,000


Fill to top of cross shafts with silicone diff oil.
Füllen Sie das Gehäuse bis zum Wellenkreuz mit Silikon-Differential-Öl.

Remplissez d'huile jusqu'en haut des arbres transversaux avec de l'huile silicone pour différentiel.

STEP B-02


Center
Mitte
Central**1x** Make 1
1 Stück 1 fois

109836 Lightweight center differential set (48T)



#3,000







ORI44416
Silicone Oil #3,000
Silikon Daempferoel #3,000
Huile silicone 3,000



Fill to top of cross shafts with silicone diff oil.
 Füllen Sie das Gehäuse bis zum Wellenkreuz mit Silikon-Differential-Öl.


Remplissez d'huile jusqu'en haut des arbres transversaux avec de l'huile silicone pour différentiel.

STEP C-01




BAG - D

STEP D-01




BAG - E

STEP E-01




BAG - E

STEP E-02




BAG - F

STEP F-01



STEP F-02






Visit

www.HBRACING.com


- Latest set-up sheets
- Instruction updates
- Newest option parts
- Team info
- Race news





STEP F-03

STEP F-04**STEP F-05**


STEP F-06




STEP F-07-1**STEP F-07-2**

STEP G-01

Z234
Cap Head Screw M2x5mm
(1.5 mm)




Z084
Flat Head Screw M3x12mm
(2 mm)



B028
Ball Bearing 6x10x3mm

67195



Z307
Flat Head Screw M4x10mm (Thin Type)
(2.5 mm)


STEP G-02

Z354
Button Head Screw M3x12mm
(2 mm)

(2 mm)

Z216
Button Head Screw M3x15mm
(2.5 mm)


94554
Button Head Screw M4x10mm
(2.5 mm)




Z224
Washer
M3x8mm

Z663
Lock Nut M3
(5.5 mm)



Z216
Button Head Screw M3x15mm
(2 mm)






STEP G-03



Example: Assembled E817




STEP H-01**STEP H-02**

STEP H-03

STEP H-04**STEP H-05-1**


STEP H-05-2**STEP H-05-3**

STEP H-06




BAG - H

STEP H-07




BAG - I


STEP I-01







STEP J-01



STEP J-02





STEP J-03**BREAK-IN Z684 NUTS**



STEP J-03**ADJUSTABLE SHORTY BATTERY POSITION**

STEP K-01


Paint from inside using polycarbonate paint.
Lackieren Sie von Innen mit Farben für Polycarbonat.
Peignez à partir de l'intérieur, en utilisant une peinture polycarbonate.

Remove protective film before using.
Entfernen Sie vor dem Fahren die Schutzfolie.
Retirez le film de protection avant utilisation.


**STEP K-02**

STEP K-03**STEP K-04**

EXPLODED VIEW



EXPLODED VIEW




Driver _____

Date _____

Track _____

Event _____

Track Condition**Front**

Ride Height _____

Camber Angle _____

Toe Angle _____

Sway Bar _____

Shock Length _____

**Shocks**


Oil _____

Piston _____

Bladder _____

Spring _____

Notes _____

Rear

Ride Height _____

Camber Angle _____

Sway Bar _____

Shock Length _____

**Shocks**


Oil _____

Piston _____

Bladder _____

Spring _____

Notes _____



Notes _____

Motor

Brand / Model _____

Notes _____

Spur gear _____

Pinion Gear _____

Tires

Front _____ | Rear _____

Brand _____

Compound _____

Insert _____

Wheel _____

Notes _____

Battery

Brand / Model _____

Notes _____

Diff Oils

Front _____

Center _____

Rear _____

Brand _____





Oil _____

Driver Team Driver

Date

Track

Event

Track Condition **Base Set-Up for Dirt****Front****Ride Height****27****Camber Angle****1°****Toe Angle****1°****Sway Bar****2.2****Shock Length****106mm****Shocks****Oil****500****Piston****6 x 1.3****Bladder****Std****Spring****Yellow****Notes****Rear****Body**Body Brand / Model
PL PREDATOR**Wing**Wing Brand / Model
PLWing Stay
 High Low**Ride Height****28****Camber Angle****1°****Sway Bar****2.4****Shock Length****124mm****Shocks****Oil****400****Piston****6 x 1.3****Bladder****Std****Spring****Blue****Notes****Front Arms**Standard
Hard Front Arm Caps
PLASTIC2 mm
2 mmRear Arm Caps
PLASTIC

0 mm

Rear Arms
 Standard
 Hard

4 mm

MotorBrand / Model
ORION 2100KV

Notes

Spur gear

48

Pinion Gear

20**Tires**

Front

Rear

HB Megabite

Compound

Pink


Insert

Std

Wheel

HB V2

Notes

**Battery**Brand / Model
ORION CARBON

Notes

SHORTY**Diff Oils**

Front

Center

Rear

Brand
Oil
**ORION
5000****ORION
3000****ORION
2000****Notes**

Parts List

Parts #	Description	Parts #	Description
6123	BODY PIN (8MM/SILVER/LARGE/20PCS)	114738	DIFF SHARED PARTS SET
66247	STEERING BALL END 6.8MM (4PCS)	114743	DIFF RING / INPUT GEAR SET (43/13)
67195	LIGHTWEIGHT STEERING POST (2PCS)	114744	SHOCK PISTON SET V2 (16MM/ORANGE/6 PAIRS)
67196	LIGHTWEIGHT WHEEL HEX HUB (2PCS)	114745	BIG BORE SHOCK CAP SET V2 (2PCS)
67197	LIGHTWEIGHT OUTDRIVES (2PCS)	114749	ALUMINUM SERVO SAVER ARM (BLACK)
67199	LIGHT WEIGHT BALL (6MM/4PCS)	114750	CLAMPING SERVO SAVER NUT (ORANGE)
67200	LIGHTWEIGHT DIFFERENTIAL SHAFT (2PCS)	114751	SERVO SAVER DUST COVER (4PCS)
67202	LIGHTWEIGHT SHOCK STAND OFF (2PCS)	114752	STEERING BRACE V2
67203	LIGHTWEIGHT STEERING BUSHING (2PCS)	114753	SHOCK CAP BUSHING (4PCS)
67204	LIGHT WEIGHT FIXING BALL (4PCS)	114754	SHOCK BELLOW BLADDER (4PCS)
67206	LIGHT WEIGHT STEERING PUSH ROD BALL (4PCS)	114755	D815 CENTER BULKHEAD SET
67207	LIGHT WEIGHT SWAY BAR HOLDER (4PCS)	114761	BUTTON HEAD SCREW M2.5X6MM (HEX SOCKET/10PCS)
67211	LIGHTWEIGHT DIFF AXLE SHAFT (2PCS)	114762	INPUT SHAFT CLIP / SHIMS SET (4PCS)
67213	LIGHT WEIGHT SHOCK END BALL (4PCS)	114763	ALUMINUM WING MOUNT WASHER (BLACK/2PCS)
67351	SHOCK END/SHOCK SPRING RETAINER SET	114776	SHIM 4X10X0.3MM (12PCS)
67376	SERVO ARM SET	114777	SHOCK CARTRIDGE MAINTENANCE SET (1 PAIR)
67394	SERVO SAVER CRANK SET	114778	BIG BORE SHOCKS V2 SHARED PARTS SET (1 PAIR)
67397	STEERING CRANK SET	114780	STUB AXLE (BEARING PIN CAPTURE/2PCS)
67398	STEERING PLATE	114930	BIG BORE SHOCK BODY 29MM (2PCS)
67464	STEERING TURNBUCKLE 4X55MM (2PCS)	114931	BIG BORE SHOCK BODY 38MM (2PCS)
67491	STEERING LINKAGE SET	114932	STUB AXLE (SLEEVE PIN CAPTURE/2PCS)
67492	17MM WHEEL NUT (BLACK/4PCS)	204000	CHASSIS BRAKE CARBON SET (E817)
67516	BALL END SET	204001	CHASSIS ROD FRONT SET (E817)
67528	BIG BORE SHOCK SPRING ADJUST NUT (BLACK/2PCS)	204004	SET SCREW M4X16MM
67529	BIG BORE SHOCK BOTTOM CAP (BLACK/2PCS)	204009	HUB CARRIER (817 SERIES)
67534	BALL 5.8X5.8MM (4PCS)	204012	HUB CARRIER ARM 03 (817 SERIES)
86598	WASHER 13X16X0.2MM (10PCS)	204017	CHASSIS GUARD SET (817 SERIES)
94531	FLAT HEAD SCREW M4X15MM (HEX SOCKET/10PCS)	204018	FLUSH MOUNT FASTENER (M3.0)
94554	BUTTON HEAD SCREW M4X10MM (HEX SOCKET/10PCS)	204019	CHASSIS (E817)
94675	CAP HEAD SCREW M3.5X14MM (4PCS)	204020	BATTERY HOLDER SET (E817)
94677	CAP HEAD SCREW M3.5X42MM (8PCS)	204021	BATTERY STRAP (E817)
100550	PAN HEAD SCREW M6X8MM (HEX SOCKET/10PCS)	204022	ELECTRONICS MOUNT SET (E817)
100551	LOCK NUT M2.5 (4PCS)	204024	DOG BONE 185MM (SHORT PIN)
100553	WASHER M2.9X8X0.5MM (6PCS)	204025	DOG BONE 34MM (SHORT PIN)
100554	SET SCREW M3X14MM (4PCS)	204027	D SERIES DIFF O-RINGS V2 (10PCS)
100556	FLAT HEAD SCREW M3X14MM (HEX SOCKET/10PCS)	204028	HINGE PIN (INNER)
100560	BUTTON HEAD SCREW M3X16MM (HEX SOCKET/10PCS)	204032	D-MOUNT 3.00DEG (AL)
107372	DROOP SCREW M4X10MM (4PCS)	204036	CHASSIS ROD REAR SET (E817)
107374	FLAT HEAD SCREW M2.5X6MM (HEX SOCKET/10PCS)	204037	D SERIES GEARBOX SET (LARGE BEARING)
109809	SHOCK SPRING (YELLOW/68MM/73.8GF/2PCS)	204038	INPUT GEAR (43-10) V2
109814	SHOCK SPRING (BLUE/83MM/61.8GF/2PCS)	204048	BODY MOUNT SET
109831	SHOCK SHAFT (29MM STROKE/2PCS)	204080	BHCS M3X25MM
109832	SHOCK BOOT (29MM STROKE/2PCS)	204081	MOTOR MOUNT SET (E817)
109833	SHOCK SHAFT (38MM STROKE/2PCS)	204083	FOAM ADHESIVE PAD
109834	SHOCK BOOT (38MM STROKE/2PCS)	204147	SET SCREW M4 X 25
109836	LIGHTWEIGHT CENTER DIFFERENTIAL SET (48T)	B028	BALL BEARING 6X10X3MM (2PCS)
109839	FRONT SUSPENSION ARM SET	B033	BALL BEARING 12X18X4MM (2PCS)
109841	LIGHTWEIGHT SPUR GEAR (48T)	B034	BALL BEARING 12X21X5MM (2PCS)
109842	ARM MOUNT (A)	B086	BALL BEARING 8 X 16 X 5MM (2PCS)
109843	ARM MOUNT (B)	HBC8017	TURNBUCKLE 5X51MM (2PCS)
109844	ARM MOUNT (C)	HBC8019	DIFFERENTIAL HOUSING D815
109846	HINGE PIN BUSHING SET	HBC8021	DIFFERENTIAL PADS (D815)
109847	PLASTIC SPACER SET	HBC8022	DIFFERENTIAL SHAFT
109849	HINGE PIN SET (FRONT OUTER 2PCS)	HBC8096	3X17MM SHAFT (4PCS)
109850	HINGE PIN SET (REAR OUTER 2PCS)	HBC8100	6.8MM BALL END (L) (4PCS)
109851	BUMPER	HBC8101-1	HARD STEEL DIFFERENTIAL GEAR SET
109852	SHOCK TOWER (FRONT)	Z084	FLAT HEAD SCREW M3X12MM (HEX SOCKET/10PCS)
109853	STEERING BLOCK SET (0 DEG)	Z086	FLAT HEAD SCREW M3X18MM (HEX SOCKET/10PCS)
109855	KINGPIN SET	Z150	ANTENNA PIPE SET
109857	UNIVERSAL DRIVE SHAFT SET (2PCS)	Z216	BUTTON HEAD SCREW M3X15MM (HEX SOCKET/4PCS)
109858	DRIVE SHAFT (92MM)	Z224	WASHER M3X8MM (10PCS)
109859	AXLE BOOT (8PCS)	Z234	CAP HEAD SCREW M2X5MM (10PCS)
109861	REAR SUSPENSION ARM SET	Z307	FLAT HEAD SCREW M4X10MM (HEX SOCKET/THIN TYPE/4PCS)
109863	SHOCK TOWER (REAR)	Z352	BUTTON HEAD SCREW M3X8MM (HEX SOCKET/10PCS)
110072	ROD END 6X14MM (8PCS)	Z353	BUTTON HEAD SCREW M3X10MM (HEX SOCKET/10PCS)
110112	ALUMINUM BALL 6.8X9X3MM (4PCS)	Z354	BUTTON HEAD SCREW M3X12MM (HEX SOCKET/10PCS)
111736	STEERING BLOCK BUSHING (4PCS)	Z357	BUTTON HEAD SCREW M3X20MM (HEX SOCKET/10PCS)
111739	STEERING BLOCK ARM SET (TYPE 5)	Z544	CAP HEAD SCREW M3X12MM (6PCS)
112794	WASHER SET 3X7MM (0.5MM/1.0MM/ORANGE/6PCS)	Z547	CAP HEAD SCREW M3X20MM (6PCS)
114414	WING MOUNT V2 (STANDARD)	Z548	CAP HEAD SCREW M3X22MM (12PCS)
114415	WING MOUNT V2 (+10MM)	Z663	LOCK NUT M3 (6PCS)
114621	CASTER BLOCK SET V2 (17.5 DEG)	Z676	LOCK NUT M3 THIN TYPE (4PCS)
114719	UNIVERSAL DRIVE SHAFT SET 102MM (2PCS)	Z684	FLANGED LOCK NUT M4 (4PCS)
114720	UNIVERSAL REBUILD KIT (FRONT/REAR/2 PAIRS)	Z700	SET SCREW M3X3MM (8PCS)
114721	AXLE BOOT (CENTER/REAR/4PCS)	Z702	SET SCREW M3X5MM (10PCS)
114722	UNIVERSAL DRIVE SHAFT (102MM)	Z704	SET SCREW M3X8MM (10PCS)
114737	ALUMINUM SHOCK / SWAYBAR PIN (4PCS)	Z721	SET SCREW M4X4MM (4PCS)

Option Parts List

Parts #	Description	Parts #	Description	Parts #	Description
67167	HB ALUMINUM STEERING SERVO HORN (23)	109825	LIGHTWEIGHT SPUR GEAR (46T)	204014	HUB CARRIER ARM 05 (817 SERIES)
67168	HB ALUMINUM STEERING SERVO HORN (24)	109856	STEERING BLOCK ARM SET (TYPE 4)	204015	UNIVERSAL SET (REAR)
67169	HB ALUMINUM STEERING SERVO HORN (25)	109864	D812 BUGGY BODY	204016	UNIVERSAL SET (FRONT)
109806	SHOCK SPRING (GREEN/68MM/60.8GF/2PCS)	109865	MUD GUARD SET	204031	D-MOUNT 2.75DEG (AL)
109807	SHOCK SPRING (WHITE/68MM/64.6GF/2PCS)	111740	STEERING BLOCK ARM SET (TYPE 6)	204033	D-MOUNT 3.25DEG (AL)
109808	SHOCK SPRING (BLUE/68MM/68.9GF/2PCS)	111741	WOVEN GRAPHITE ARM COVERS (FRONT)	204034	D-MOUNT 3.50DEG (AL)
109810	SHOCK SPRING (GOLD/68MM/77.9GF/2PCS)	111742	WOVEN GRAPHITE ARM COVERS (REAR)	204162	1:8 BUGGY BLACK JACK PINK COMPOUND TYRE 1PC
109811	SHOCK SPRING (RED/68MM/88.1GF/2PCS)	113476	SHOCK SPRING (ORANGE/83MM/82.1GF/2PCS)		
109812	SHOCK SPRING (RED/68MM/86.1GF/2PCS)	114201	HB 1/8 BUGGY DISH WHEELS V2 (WHITE/4PCS)		
109813	SHOCK SPRING (WHITE/63MM/57.9GF/2PCS)	114202	HB 1/8 BUGGY DISH WHEELS V2 (YELLOW/4PCS)		
109815	SHOCK SPRING (YELLOW/63MM/65.7GF/2PCS)	114620	CASTER BLOCK SET V2 (15 DEG)		
109816	SHOCK SPRING (GOLD/83MM/70.3GF/2PCS)	114622	CASTER BLOCK SET V2 (20 DEG)		
109817	SHOCK SPRING (RED/83MM/75.8GF/2PCS)	114746	FRONT SWAY BAR SET V2 (2.0, 2.2, 2.4, 2.6MM)		
109821	STEERING BLOCK SET (4 DEG)	114747	REAR SWAY BAR SET V2 (2.2, 2.4, 2.6, 2.8, 3.0MM)		
109822	STEERING BLOCK ARM SET (TYPE 3)	204010	HUB CARRIER ARM 01 (817 SERIES)		
109823	STEERING BLOCK ARM SET (TYPE 2)	204011	HUB CARRIER ARM 02 (817 SERIES)		
109824	STEERING BLOCK ARM SET (TYPE 1)	204013	HUB CARRIER ARM 04 (817 SERIES)		

NOTES



Serial Number
Seriennummer
Numéro de série
シリアルナンバー

www.hrcracing.com
Neidhart SA
Ch. du Pré-Fleuri 31
CH-1228 Plan-les-Ouates
Switzerland
Phone: +41 22 706 18 50