



F1-180/200 Revise Manual




Kit Bag C



TS01023.....1



TS0101002.....1



MR106-OR.....2



SG_M2.5X6.....1



SK_M3X3.....1


6

Attaching rear shaft



★ Refer to page 14 for ground clearance adjustment.

MR106-OR



TS01023

TS0104045

Hex wrench (2mm)

SK_M3X3

SG_M2.5X6

TS0101002

MR106-OR


TS0104045



TS0102004.....2



TS0101045.....1



MR106-OR.....1



MR106-T.....2



TS0102027.....4



TS0102006.....12



SN_M4.....1

7

Ball differential

TS0102006

White Grease
(for bearing ball 4cc)

92T-64P Spur gear

TS0102004

MR106-T

TS0104045

TS0102027

SN_M4

TS0101044

TS0102006

TS0104069

★ Fully tighten the lock nut , then loosen by a quarter turn (standard position)



Kit Bag E


(L=31mm)

TS0102007.....2




TS0102003.....2


TS0101030.....2



TS0101026.....2



TS0101027.....2



TS0101029.....2



OE_E2.0.....4



TS0102807.....2

14

OE_E2.0

TS0101027

TS0101029

TS0101026

TS0102003

OE_E2.0

TS0102007

TS0104078

TS0102807

OE_E2.0

TS0101027

TS0101029

TS0101026

TS0102003

OE_E2.0