


# TEENEX

GT-300W-V3



Thank you for purchasing this TEAMSAXO product. This high performance competition kit has been proudly manufactured by TEAMSAXO World Champion R/C car manufacturer.  
Proper assembly of this product will provide fun,safe enjoyment.

## PRECAUTIONS FOR SAFE ENJOYMENT OF YOUR R/C CAR

For children under the age of 13, parental guidance is recommended when running.

### ASSEMBLY PRECAUTIONS

Do not assemble around small children. The parts can be dangerous if accidentally swallowed.

Check the contents carefully before assembly. Please contact Customer Support if you happen to notice any defective or missing items.

You will find the assembly process much easier by carefully reading through the manual, and familiarizing yourself with the instructions.

Many different tools are required during assembly. For safety purposes, please use suitable tools. Exercise extra caution when using a sharp tool such as a hobby knife.

Many different materials are used for the parts. Use extra care when handling parts with sharp edges, such as machined metal parts.

When cutting plastic parts, watch for any flying parts.

Try to assemble any rotating parts of drivetrain parts as smooth as possible.

Bundle wires neatly away from the ground or any moving drivetrain components. Make sure that all wires are properly connected to prevent shorting.

Unnecessary modifications may be unsafe and hinder performance.

Always paint in a well ventilated area away from flames.

### PRECAUTIONS BEFORE RUNNING

Teamsaxo R/C cars are built for competition use, and some models may exceed speeds of 40km per hour. Practice common sense and run the car in open safe places, or R/C car tracks.

Do not run the car on public roads with high amounts of traffic, or in areas that may cause an inconvenience to people in that area.

R/C cars are controlled using radio frequency. In a worst-case scenario, radio interferences may cause loss of control.

If others near you are running R/C cars, confirm that they are not running on the same frequency.

R/C cars do not like water. Avoid running on rainy days, or areas with water puddles. Exposure of the electronics to water may cause loss of control or damage to the electronics.

The drivetrain of an R/C car consists of many moving parts like gears, belts, shafts, and tires. Avoid touching these areas when the battery is connected.

Many parts of an R/C car will become hot after running. Allow the parts to sufficiently cool before conducting any maintenance.

### BEGINNING A RUN


1. Place the R/C car on a stand so the wheels are off the ground.
2. Confirm that the speed controller switch is OFF, and connect the motor and battery.
3. Extend the transmitter antenna and turn the switch ON. (It is unsafe to use a transmitter with low voltage. Make sure that the transmitter batteries are good before running.)
4. Turn the speed controller switch ON.

### FINISHING A RUN


1. Turn the speed controller switch OFF.
2. Disconnect the battery.
3. Turn the transmitter switch OFF, and retract the antenna.

## ASSEMBLING TOOLS REQUIRED (NOT INCLUDED IN KIT)


### Scissors




### Modeling knife




### Side cutters




### Long nose pliers



### Hex wrench (1.5mm)



### Hex wrench (2mm)



### Tweezers



## GT-300W-V2 CHASSIS SPECIFICATION

|                    |          |                           |            |
|--------------------|----------|---------------------------|------------|
| Overall Length     | :275.3mm | Overall Width Front width | :165mm     |
| Wheelbase length   | :200mm   |                           | :265-172mm |
| Weigh Chassis only | :280g    |                           |            |

### Cap

|  |       |        |
|--|-------|--------|
|  | M3×4  | SJG304 |
|  | M3×6  | SJG306 |
|  | M3×8  | SJG308 |
|  | M3×10 | SJG310 |
|  | M3×12 | SJG312 |

### Cap screw

|  |      |        |
|--|------|--------|
|  | M2×6 | SG206  |
|  | 4#40 | SG4#40 |

### Grub screw

|  |       |       |
|--|-------|-------|
|  | M3×3  | SK303 |
|  | M3×8  | SK308 |
|  | M3×10 | SK310 |

### Lock nut

|  |    |        |
|--|----|--------|
|  | M3 | SN-M3  |
|  | M3 | SN-M3F |

### E-Ring

|  |            |         |
|--|------------|---------|
|  | E-Ring 2.0 | OE-E2.0 |
|  | E-Ring 1.5 | OE-E1.5 |

### Screw

|  |        |         |
|--|--------|---------|
|  | M2×4   | SIG204  |
|  | M2.5×4 | SIG2.54 |
|  | M3×6   | SIG306  |
|  | M3×8   | SIG308  |
|  | M3×10  | SIG310  |

### Ball bearing

|  |                     |          |
|--|---------------------|----------|
|  | ∅3.175×∅7.938×2.779 | FR2-5ZZ  |
|  | ∅6.35×∅9.525×3.175  | R168-2RS |
|  | ∅6.35×∅9.525×3.175  | FR168-ZZ |



① ~ ④  
Kit Bag A




TS0102010 .....2



SJG\_M3X4 .....2

## ① Lower deck



TS0102010 .....3



SJG\_M3X6 .....1





SJG\_M3X4 .....2



SG\_M2X6 .....2

## ② Lower brace




TS0201031 .....2



SJG\_M3X8 .....2

## ③ Attaching lower brace






TS0104038 .....2




SG\_M2X6 .....4

4



★ Do not over tighten.




★ Note direction




5

Kit Bag B



TS0501028 .....1



TS0501029 .....1



SIG\_M3X10 .....2




SJG\_M3X6 .....4

5

Motor mount

★ Assemble on a flat surface to prevent distortion.



6 ~ 7

Kit Bag C

◎ I (ø3.0xø2.0x0.5)

TS0501020 .....8

◎ I (ø6.4xø8.4x1.0)

TS0501017 .....2

◎ I (ø6.35xø9.525x3.175)

R168-2RS .....2




SG\_M3X8 .....1




SG\_4#40 .....1

6


Attaching rear shaft



★ Refer to page 13 for ground clearance adjustment.







TS0102004.....2



TS0501021.....1



FR168ZZ (φ6.35×φ9.525X3.175).....2



R168-2RS (φ6.35×φ9.525X3.175).....1



TS0102034.....4

○ (1/8 mm)


TS0508007.....12



SN\_M3\_F.....1

7

## Ball differential



★ Fully tighten the lock nut , then loosen by a quarter turn ( standard position )



8 ~ 12

## Kit Bag D



TS0104042.....2



TS0102001.....2



TS0101007.....2




SIG\_M3X6.....2



SK\_M3X8.....2

8

## Body mount plate




9

(h=15mm)

TS0201026.....2



SJG\_M3X6.....4




|                                                                                                                                                                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div data-bbox="132 97 164 129"></div> <div data-bbox="124 135 391 168">TS0101007.....3</div> <div data-bbox="127 189 178 222"></div> <div data-bbox="124 232 391 265">SJG_M3X6.....2</div> <div data-bbox="127 286 164 319"></div> <div data-bbox="124 334 391 366">SJG_M3X6.....1</div>                                                                                                                    | <div data-bbox="459 97 510 146">10</div> <div data-bbox="699 118 1300 657"> </div>                                                                                                                                             |
| <div data-bbox="132 758 338 791"> (L=13.5mm)</div> <div data-bbox="124 804 391 836">TS0104026.....4</div> <div data-bbox="127 858 274 890"></div> <div data-bbox="124 905 391 937">TS0101018.....2</div> <div data-bbox="127 959 252 991"></div> <div data-bbox="124 1002 391 1034">TS0104080.....2</div> <div data-bbox="127 1056 172 1088"></div> <div data-bbox="124 1084 391 1116">SK_M3X10 .....2</div> | <div data-bbox="459 758 510 808">11</div> <div data-bbox="837 750 1292 819">       ★ Apply different viscosities of grease to the piston to adjust roll damper hardness.     </div> <div data-bbox="470 786 1484 1358"> </div> |
| <div data-bbox="127 1422 178 1455"></div> <div data-bbox="124 1470 391 1502">SIG_M3X6.....2</div>                                                                                                                                                                                                                                                                                                            | <div data-bbox="459 1422 510 1472">12</div> <div data-bbox="614 1401 1364 2015"> </div>                                                                                                                                        |



13 ~ 19  
Kit Bag E


- TS0101007.....2
- TS0202001.....2
- ⊙ □ (L=2.5mm)
- TS0101029.....2
- SIG\_M3X8.....2
- SIG\_M2.5X4.....2

### 13 Attaching front uprights




- TS0204004.....2
- TS0204002.....2
- TS0202003.....2
- TS0204005.....2


### 14



- TS0201001.....2
- TS0204001.....2
- SJG\_M3X12.....4
- SIG\_M3X10.....4
- TS0204004.....2

### 15








TS0204006 .....2




TS0204007 .....2

19



(20 ~ 23)  
Kit Bag F



20



TS0101053 .....2



SJG\_M3X6 .....2



TS0501025 .....2



TS0101007 .....2



TS0102017 .....1



TS0102016 .....2




SIG\_M3X6 .....6



SIG\_M3X10 .....1

21






24 ~ 28  
Kit Bag G


TS0101007 .....1  
SIG\_M3X6 .....3

22




SIG\_M3X8 .....2

23




TS0501008 (L=43mm) .....2  
TS0104027 (L=18.5mm) .....4

24 Servo saver





25



22 ~ 28  
Kit Bag G

— (L=22mm)

TS0502001.....1

⊙ (ø2Xø6X2.0)

TS0505002.....1

○ (ø6Xø8X1.0)

TS0505003.....1

○ (ø10Xø12X1.0)

TS0505001.....1


⊙

TS0502005.....1

⊙


OE\_E1.5.....2

## 26 Damper assembly




## 27 Dampers oil

1.Pull up piston and pour oil into cylinder .Remove air bubbles by slowly moving piston up and down.



2.Pull up piston ,attach oil seal and absorb oil overflow with tissue paper.






TS0502003.....1



SK\_M3X3.....1

## 28 Attaching dampers

★ Select damper spring according to running surface condition.



(29 ~ 35)  
Kit Bag H



TS0104006.....2




TS0504001.....2



SJG\_M3X10.....2

## 29




TS-P034\_R6.....4



TS0104003.....2

## 30






TS-P034\_R6.....2



TS0104003.....2





TS0104010.....2



SIG\_M3X8.....2

**31**

★ Adjust snap pin positions according to the body.




TS0505001.....1

**32**

Battery assemble position

★ According to the back groove of chassis bind the battery with tape.




TS0201007.....1



SJG\_M3X4.....2

**33**



★ Tighten up into nylon portion.



## 34 Attaching wheels

○ (ø3.175Xø7.938X2.779)


FR2-5ZZ.....4



SN\_M3.....2

○ (ø4.7Xø3.2X0.4)

TS0202005.....2



## 35




SG\_4#40.....6



SK\_M3X3.....1



SIG\_M3X8.....3



# SETTING - UP



- Record various running conditions and settings on the setting sheet on page 13.

## TOE-IN AND TOE-OUT

Toe-in and toe-out

★Adjust rod length by rotating adjuster.

★Make sure the servo is in neutral.





★Adjust according to the track layout.

## CAMBER ANGLE

Camber angle






★Adapt for the draw bar to adjust camber angle.



## GROUND CLEARANCE

Front

★Ways for adjusting the turnbuckle to fit the hardness of the front suspension.



★Use different washers to adjust the height and width of rear axle.

**NOTE:**



VA PON INDUSTRIAL CO.,LTD

<http://www.saxoracing.com>

E-mail:saxo@saxoracing.com

1F.NO.1,Ln,122,Chelutou St.Sanchong Dist,New Taipei City 241Taiwan 24157



TS0508009  
Ver 1.0

