

**XRAY T2008**

### FRONT

**CASTER** 0° ☐ 2° ☐ 4° ☒ 6° ☐

**DIVE** ☐ **ROLL-CENTER** ☐

+0.75 ☒ 0.00 ☐ -0.75 ☐

**SHIM** 0 /mm

+0.75 ☒ 0.00 ☐ -0.75 ☐

**WHEELBASE**/mm 0 1 1

**RIDE HEIGHT**/mm 5.2

### REAR

**SQUAT** ☐ **ROLL-CENTER** ☐

+0.75 ☐ 0.00 ☒ -0.75 ☐

+0.75 ☐ 0.00 ☐ -0.75 ☐

**RIDE HEIGHT**/mm 5.2

### FRONT

**C-HUB** M ☒ H ☐ ALU ☐

**STEERING BLOCK** M ☒ H ☐ ALU ☐

**OFFSET** STANDARD ☒

**SHIM** 1 /mm

**UPPER SHOCK POSITION** 5 4 3 2 1

**QUICK ROLL CENTER POSITION** 3+ 4+ 3 2 1

**LONG** ☒ **SHORT** ☐

**MEASURE UNDER ARM** 8 7 6 5 4 3 2 1 0 -1 -2

**DOWNSTOP** /mm 6.2

### REAR

**REAR HUB** M ☐ H ☐ ALU ☐

**OFFSET** STANDARD ☒

**SHIM** 1 /mm

**CAMBER LINK LOCATION** 1 2

**LONG** ☒ **SHORT** ☐

**MEASURE UNDER ARM** 8 7 6 5 4 3 2 1 0 -1 -2

**DOWNSTOP** /mm 5.2

### FRONT

**OUT** 0.5 **IN** ☐

**SHIM UNDER SHOCK** SHIM /mm

**SHIM FRONT** SHIM 1.5 /mm

**SHIM REAR** SHIM 1.5 /mm

**OUTER ACKERMANN POSITION** 1 2

**INNER ACKERMANN POSITION** 1 2

**SERVO SAVER** 1 2 3 4 5

**TOE** /deg. **FINAL TOE IN** 3 **OUTBOARD TOE** 0

**ANTI ROLL-BAR** SHIM UNDER SHOCK SHIM /mm

**SHIM FRONT/REAR** 1.5 mm ☐ NO shim ☒ OTHER ☐

**INBOARD SHIMS** SHIM /mm 2.5 ☒ 2.5° 1.9 ☐ 2° 1.5 ☐ 1.5° 1.5 ☐ 1° 0.75 ☐ 0.5° 0.4 ☐ 0° 0 ☐

### REAR

**SHIM** /mm 2.5 ☒ 2.5° 1.9 ☐ 2° 1.5 ☐ 1.5° 1.5 ☐ 1° 0.75 ☐ 0.5° 0.4 ☐ 0° 0 ☐

### FRONT

**CAMBER** /deg. 1.5

**FRONT ARM** HARD (H) ☒ EXTRA-HARD (XH) ☐

### REAR

**CAMBER** /deg. 1.5

**REAR ARM** HARD (H) ☒ EXTRA-HARD (XH) ☐

### FRONT

**BALANCE** /g

**ECCENTER** STANDARD ☒ 1 ☐

**DIFF. POSITION** UP ☒ DOWN ☐

**BALANCE** /g

### REAR

**BALANCE** /g

**ECCENTER** STANDARD ☒ 1 ☐

**DIFF. POSITION** UP ☒ DOWN ☐

**BALANCE** /g

### FRONT

**CHASSIS MULTI-FLEX SETTING** CHASSIS

**CENTRAL ALU STAND**

**FRONT ALU STANDS (US)**

**BRACE (EU)** ☐

### REAR

**REAR ALU STANDS (US)**