

## #91755 RC10B6/B6D Titanium Screw Kit

Please refer to your instruction manual to match up screw sizes and locations.

### Installation Instructions

This kit does not contain every screw used in the RC10B6. It only contains the screws which we feel are reliable enough to be titanium. If you wish to add any others, do so at your own risk. We highly recommend that you pre-thread all holes before attempting to install the titanium screws. A small drop of oil on the threads will help make installation easier.

### Flat Head Screws

#### 3mm x 8mm

- 6 – Side rail to chassis
- 2 – Arm mount [C] to chassis

#### 3mm x 10mm

- 4 – Side rail to chassis
- 3 – Motor plate to gear box
- 4 – Gear box to chassis (B6D only)
- 6 – Gear box to chassis (B6 only)


#### 3mm x 12mm

- 4 – Front tower to top plate
- 2 – Chassis brace to chassis
- 2 – Wing to wing mount

#### 3mm x 16mm

- 2 – Front bumper to chassis
- 2 – Front bulkhead to chassis
- 2 – Rear gear box brace to chassis

- = Flat Head
- = Button Head



### Button Head Screws

#### 3mm x 6mm

- 2 – Front axle
- 2 – Gear cover

#### 3mm x 8mm

- 4 – Steering block arm to steering block
- 4 – Servo mount to servo
- 1 – Servo horn to servo
- 2 – Motor to motor plate

#### 3mm x 10mm

- 2 – Servo mount to side rail
- 2 – Battery strap nut to battery strap

#### 3mm x 12mm

- 2 – Top plate to front ball stud mount
- 2 – Top plate to side rail
- 2 – Steering bell crank to steering rack
- 4 – Wing mount to rear tower
- 4 – Rear tower to gear box

#### 3mm x 14mm

- 4 – Steering block to caster block
- 4 – Gear box halves (B6D only)
- 6 – Gear box halves (B6 only)
- 2 – Shock to rear arm
- 2 – Gear box to rear ball stud mount

#### 3mm x 20mm

- 2 – Shock to front tower
- 2 – Shock to front arm
- 2 – Steering bell crank to front ball stud mount

#### 3mm x 24mm

- 2 – Shock to rear tower

