

9	Over-heat Protection	X Enable	Disable							
10	BoostTiming**	X 0°	User Setting:				(0°-16°   1° steps)			
13	TurboTiming	10°	User Setting:				(0°-20°   1° steps)			
14	Turbo Slope Rate	3°/0.1s	6°/0.1s	12°/0.1s	18°/0.1s	X 24°/0.1s	Fastest			
15	Turbo Delay	X 0s/off	0.1s	0.2s	0.3s	0.4s	0.5s	0.6s	0.7s	0.8s
	**Boost Timing is not available for speed controllers with 0° timing software									