



FRONT

LRP Flow WorksTeam ESC

v4.0 software 3-2-0-1-1-0-0



ı			_	
ı			ı	
	ı	L	Į,	
ŀ	4	-	4	
ı	٠	ń	r	

TIRE Pro-line Pin Point (control tires) **INSERTS** Pro-line (conrol inserts)

SETTING

REAR TIRE


Pro-line Pin Point (control tires)

INSERTS Pro-line (control inserts) ΑE

WHEELS ΑE

WHEELS

Editable by Arn0 at PetitRC.com



COMMENTS