
: Tuning Tips - Front Arm Mount Pill Insert Setups

Standard Position

Use this position as a reference when changing pill locations.

> Kick-up: 10° Roll Center: +0 Pin Width: +0






Possible Insert Locations


Insert Hole Locations


.5




from center Hole 1.0° or 0.7mm from center

The aluminum front arm mounts utilize eccentric pill inserts to make fine adjustments to kick-up, pin height, and pin width. Adjustments can be made using the supplied inserts (#92014)







Total Caster Angle

		Kick Up Angle			
		8°	9°	10°	11°
ster Block Angle	6°	14°	15°	16°	17°
	7°	15°	16°	17°	18°
	8°	16°	17°	18°	19°
	9°	17°	18°	19°	20°
Cast /	10°	18°	19°	20°	21°

: Tuning Tips - Rear Arm Mount Pill Insert Setups

Standard Position

(1)

(1)


Use this position as a reference when changing pill locations.


> Toe: 3° Anti-Squat: 2° Roll Center: +0 Pin Width: +0




= -0.7mm
















from center

Hole 1.0° or 0.7mm from center

The aluminum front arm mounts utilize eccentric pill inserts to make fine adjustments to kick-up, pin height, and pin width. Adjustments can be made using the supplied inserts (#92014)





= 3°