


Rear C & D Arm Mount Pill Insert Setup

*Works for: B6.1, B6.1D, T6.1, SC6.1, B64,
and B64D*


The aluminum rear arm mounts utilize eccentric pill inserts to make fine adjustments to anti-squat, toe, pin height, and pin width.

Adjustments can be made using #92014 inserts.



Insert Hole Locations

Dot indicates orientation
of hole position



Hole 0.5° or 0.35mm
from center



Hole 1.0° or 0.7mm
from center

Number indicates degree of change:
0.5°, 1.0°, & 0° (center dot)

Standard Position

Use this position as a reference
when changing pill locations.

Toe: 3°

Anti-squat: 1°

Roll Center: +0

Pivot Width: +0

C MOUNT



D MOUNT




Pin Height

Higher pin = Higher roll center

Lower pin = Lower roll center

Pin Height
Higher pin = Higher roll center
Lower pin = Lower roll center




<u>C MOUNT</u>	<u>D MOUNT</u>	
		= +0.7mm
		= +0.35mm
		= 0mm
		= -0.35mm
		= -0.7mm

Pin Width

More distance = wider pivot

Less distance = narrower pivot

Pin Width
More distance = wider pivot
Less distance = narrower pivot



<u>C MOUNT</u>	<u>D MOUNT</u>	
		= +1.4mm
		= +0.7mm
		= 0mm
		= -0.7mm
		= -1.4mm

These are some of the possible and most popular toe and anti-squat combinations when using adjustable inserts. The same toe and anti-squat angles can be achieved by using different combinations of inserts but will differ in pin width and height. Take note of these differences when making adjustments.

Toe Angle

More angle = More toe in

Less angle = Less toe in



Toe Angle More angle = More toe in Less angle = Less toe in		
C MOUNT	.5	D MOUNT
		= 3°
		= 3.5°
		= 4°
		= 2.5°
		= 3°
		= 3.5°
		= 2°
		= 2.5°
		= 3°

Toe Angle

More angle = More toe in

Less angle = Less toe in



<p>Toe Angle More angle = More toe in Less angle = Less toe in</p>			
<u>C MOUNT</u>		<u>D MOUNT</u>	
		= 3°	
			= 4°
			= 5°
		= 2°	
			= 3°
			= 4°
		= 1°	
			= 2°
			= 3°

Anti-squat Angle

More angle = More anti-squat

Less angle = Less anti-squat



Anti-Squat Angle More angle = More anti-squat Less angle = Less anti-squat		
<u>C MOUNT</u>		<u>D MOUNT</u>
		*Shown in 0.5° changes
		= 1°
		= 0.5°
		= 0°
		= 1.5°
		= 1°
		= 0.5°
		= 2°
		= 1.5°
		= 1°

Anti-squat Angle

More angle = More anti-squat

Less angle = Less anti-squat



Anti-Squat Angle More angle = More anti-squat Less angle = Less anti-squat		
C MOUNT		D MOUNT
		*Shown in 1° changes
		= 1°
		= 0°
		= -1°
		= 2°
		= 1°
		= 0°
		= 3°
		= 2°
		= 1°